# PWI-AC75Watt Series
# Prudent Way Universal Netbooks/Laptops/LCDs 75 watt AC Adapter Compatibility List

PRUDENT WAY

A B C E F G H K L(Dell) M(HP) N(ASUS) O(HP) P(Tablet) R(ASUS)

## Notebook Connectors Compatibility List

| Tip | V | Acer |
|---|---|---|
| E | 19V | Aspire One Series: 531h 10.1", 531h-1440, 531h-1766, 751h 11.6", 751h-1021, 751h-1080, 751h-1145, 751h-1153, 751h-1192, 751h-1196, 751h-1211, 751h-1259, 751h-1273, 751h-1279, 751h-1346,751h-1351, 751h-1373, 751h-1378, 751h-1401, 751h-1442, 751h-1522, 751h-1545, 751h-1893, 751h-1948, A110-1041, A110-1113, A110-1137, A110-1178, A110-1295, A110-1545, A110-1588, A110-1626, A110-1662, A110-1691, A110-1698, A110-1722, A110-1812, A110-1831, A110-1834, A110-1888, A110-1948, A110-1955, A110-1995, A150-1001, A150-1006, A150-1029, A150-1035, A150-1049, A150-1068, A150-1083, A150-1126, A150-1137, A150-1141, A150-1172, A150-1178, A150-1220, A150-1249, A150-1316, A150-1329, A150-1347, A150-1348, A150-1359, A150-1382, A150-1400, A150-1405, A150-1423, A150-1435, A150-1444, A150-1447, A150-1457, A150-1485, A150-1493, A150-1504, A150-1505, A150-1532, A150-1546, A150-1553, A150-1555, A150-1570, A150-1572, A150-1576, A150-1577, A150-1588, A150-1622, A150-1635, A150-1649, A150-1662, A150-1672, A150-1679, A150-1690, A150-1706, A150-1742, A150-1777, A150-1784, A150-1786, A150-1798, A150-1834, A150-1864, A150-1887, A150-1890, A150-1905, A150-1949,A150-1983, A150-1987, A150-1995, A150-1997, D150-1044, D150-1125, D150-1165, D150-1186, D150-1197, D150-1240, D150-1322, D150-1462, D150-1577, |
| p | 12V | **Iconia A** A100, A101, A200, A210, A211, A500, A501, A511, A700, A701 |

| Tip | V | Asus |
|---|---|---|
| F | 9.5V (9V) | Eee PC: 701/701SD, 2G , 2G Surf, 4G, 4G Surf, 8G |
| | 12V | 900, 900A, 900HA, 900HD, 900SD, 901, 904HA, 904HD, 904HG, MK90H, T91, T91MT, S101, S101H, T101M, 1000, 1000H, 1000HA, 1000HAE, 1000HC, 1000HD, 1000HE, 1000HG, 1000HT, 1000HV, 1001HA, 1001P, 1001PX, 1002HA, 1003HAG,1004DN |
| | 19V | 1005HA, 1005PE, 1005PR, 1008HA, 1008P, 1015PE, 1015PED, 1015PEM, 1016P, 1018P, 1101HA, 1101HAB, 1104HA, 1106HA, 1201HA, 1201T, 1215N, 1215PN, 1218, EeeTop PC: ET1601, ET1602, ET2202, ET2203 |
| N | 19V | Asus Eee PC 1005HA Series, 1005, 1005H, 1005HA, 1005HA-A, 1005HAB, 1005HA-E,1005HA-P, 1005HA-V, 1005HA-EU1X, 1005HA-EU1X-BK, 1005HA-PU1X, 1005HA-PU1X-BK, 1005HA-PU1X-BU, 1005HA-VU1X, 1005HA-VU1X-BK, 1005HA-VU1X-WT, 1005HA-VU1X-BU, 1005HA-VU1X-PI.<br>1008HA Series, 1101HA Series, 1101HA, 1101HGO, 101HA-MU1X, 101HA-MU1X-BK, 1104HA Series, 1106HA Series, 1001P, 1001HA |
| C | 19V | **Asus VivoBook** S400, S400CA, S500, S500CA, S500CA-HCL1002H, S500CA-SI5030ST, S505C series, S505CA series, S505CB series, S505CM series, S550, S550C, S550CA series, S550CB series, S550CM series, S551CA, S551LB, X502CA-BI3070SB, V550C Series, V550CA Series, V550CM Series |
| P | 19.5V (19V) | **Eee Pad** B121, B121-A1, EP121, Eee Slate B121, B121-A1, EP121 |

| Tip | V | ASUS(Cont.) |
|---|---|---|
| R | 19V | F201E SERIES, F201E-KX052H, F201E-KX063H, F201E-KX064H, F201E-KX065DU, F201E-KX065H, F201E-KX066DU, F201E-KX066H, F201E-KX067DU, F201E-KX067H, F201E-KX068DU, F201E-KX068H, F202E SERIES, F202E-CT028H, F202E-CT059H, F202E-CT063H, F202E-CT133H, F202E-CT148H, Q200E SERIES, Q200E-BHI3T45, S200E-CT157H, S200E-CT158H, S200E-CT182H, S200E-CT57H, S200E-RHI3T73, Special Edition VivoBook X202E Pink, Taichi 21TAICHI 21 SERIES, TAICHI 21-CW001H, TAICHI 21-CW001P, TAICHI 21-CW002H, TAICHI 21-CW003H, TAICHI 21-CW004H TAICHI 21-CW005P, TAICHI 21-CW009H, Taichi 21-DH51 |
| | | UX21A Series UX21A, UX302 Series UX301LA/UX302LA UX302LG, UX31A Series UX31A-1AR4/UX31A-1AR5/UX31A-1AR7, UX31A-AB71/UX31A-AB72, UX31A-BHI5T11, UX31A-DB51/DB52/DB71/DB72,UX31A-DH51/DH71/DH71-CA/DH71-CB, UX31A-R4002V/R4003V/R4003X/R4004V/R4005V, UX31A-R4005X, UX31A-R5007V, UX31A-R5008V/R5102F/R5102H/R5202H, UX31A-R7202F, UX31A-RB71, UX31A-XB52/XB72, UX-32A Series UX32A-DB31/DB51/DB71, UX32A-R3001V/R3002V/R3007V/R3008/R3013V/R3502H, UX32VD Series UX32VD-BHI5N57/BHI7N55, UX32VD-DB51/DB71/DB72 UX32VD-DH71, UX32VD-R3001H/R3001V/R3001X, UX32VD-R4002H/R4002P/R4002V/R4002X/R4006V, UX32VD-R43317 UX32VD-R5504H/R7504F |

| Tip | V | Dell |
|---|---|---|
| E | 19V | Inspiron Mini: 9, 10, 10v, 12, 910, 1010, 1011, 1012, 1210, P04t, PP19s, PP39s, PP40s, Nickelodeon Vostro: A90, PP39S |

| Tip | V | Fujitsu |
|---|---|---|
| C | 19V | Lifebook mini: MH330, MH380, M2010, M2011 |

| Tip | V | Gateway |
|---|---|---|
| E | 19V | LT 10 Series: 1001, 1004u, 1005, 1005u, LT 20 Series: 2001u, 2002i, 2003i, 2005U, 2012, 2012H, 2013, 2013H, 2016U, 2021U, 2022U, 2023U, 2024U, 2027H, 2028H, 2030U, 2032U, 2033U, 2036U, 2041U, 2044U, LT 21 Series: 2100, 2101, 2102H, 2103H, 2104U, 2106H, 2106U, 2107H, 2108U, 2110U, 2113U, 2114U, 2115U, 2118U, 2119U, 2120U, 2122U, 2123U, LT 22 Series / LT 23 Series: 2315U, 2316U, 2318U, 2319U, 2320U, 2321U, LT 30 Series: 3005U, LT 31 Series: 3101U, 3102i, 3103U, 3104E, 3104G, 3105G, 3107U, 3108H, 3110H, 3111H, 3113H, 3114U, 3115H, 3116H, 3117U, 3118U, 3119U, LT 32 Series: 3200, 3201U, EC Series: EC14, EC1400, EC18, EC1800 |

| Tip | V | Hp |
|---|---|---|
| G | 19V | Mini 700 Series: 700EA, 700ED, 700EE, 700EF, 700EI, 700EK, 700EL, 700EN, 700ER, 700ES, 700ET, 700EW, 701ED, 701EG, 701EI, 701EM, 701EN, 701ER, 701ES, 701ET, 702, 703, 705, Mini 1000 Series: 1000 CTO, 1001TU, 1001XX, 1002TU, 1003TU, 1004TU, 1005TU, 1006TU, 1007TU, 1008TU, 1009TU, 1010LA, 1010NR, 1010TU, 1011TU, 1012TU, 1013TU, 1014TU, 1015TU, 1016TU, 1017TU, 1020LA, 1021TU, 1022TU, 1023TU, 1024TU, 1030NR, 1033CL, 1035NR, Mini 1100 Series: 1100CM, 1101TU, 1102TU, 1103TU, 1104TU, 1105TU, 1106TU, 1107TU, 1108TU, 1109TU, 1110LA, 1110NR, 1110TU, 1112TU, 1113TU, 1114TU, 1115NR, 1123TU, 1124TU, 1125NR, 1125TU, 1126NR, 1126TU, 1127TU, 1129TU, 1130CM, 1131TU, 1133CA, 1135CA, 1137NR, 1139NR, 1140NR, 1141NR, 1150BR, 1150CM, 1150LA, 1150NR, 1151NR, 1152NR, 1153NR, 1160CM, 1170CM, 1180CM, 1190BR, 1115TU, 1116NR, 1116TU, 1117TU, 1118TU, 1119TU, 1120BR, 1120LA, 1120NR, 1120TU, 1121TU, 1122TU, Mini 210 Series. |
| F | 19.5V (19V) | Mini 311 Series, Mini 5100 Series |
| M | 19V | HP 2133 Mini-Note PC, 2533t Mobile Thin Client, HP Compaq 2230s , 2510p , 2710p , 6530b, 6720s, 6720t Mobile Thin Client, 6730b, 6730s, 6735s, nc2400, nc4200, nc4400, nc6120, nc6140, nc6220, nc6230, nc6320, nc6400, nx6110, nx6115, nx6325, nx7300, nx7400, tc4200 Tablet PC, tc4400 Tablet PC, EliteBook 2530p, EliteBook 2730p, Pavilion DV4-1000 Series, DV4-1000, DV4T-1000, DV42-1000 CTO, Pavilion DV5-1000 Series, DV5-1120US, DV5-1124CA Pavilion DV7 |
| O | 19V | **HP Envy** 4 series, 6 series, Pro 4 series, SLEEKBOOK 4T series, SLEEKBOOK 6 series, SPECTRE XT series, ULTRABOOK 4 series, ULTRABOOK 6T series |

| Tip | V | Lenovo |
|---|---|---|
| C | 20V | IdeaPad: S9, S9e, S10-2 (10"), S10-3 (10"), S10-3t, S10c, S10e, S12 (12"), U150 (11"), U160<br>ThinkPad: X100e (11"), X201 (12"), X201i |

| Tip | V | MSI |
|---|---|---|
| C | 20V | U Series: U100-001US, 002US, 004US, 013US, 016US, 018US, 030US, 035US, 036US, 039US, 043US, 053US, 219US, 222MY, 244MY, 279US, 280US, 286MY, 411US, 420US, 422CA, 427US, 432US, 439US, 451US, 631US, 641US, 843US, 869US, 876US, U110-031US, U115-021US, U120-001US, 020US, 024US, U123-001US, 002US, 003US, 004US, 019US, 020US, 025US, 033US, U130-416US, 417US, U135-204US, 205US, 206US, 208US, 210US, 411US, 413US, 415US, 628US, 643US, 644US, U135-204US, 205US, 206US, 208US, 210US, 411US, 413US, 415US, 628US, 643US, 644US, U135DX-1208US, U160-006US, 007US, U210-006US, 008US, U230-033US, 040US, U230 Light-087US, L Series: L1300-441US L1350-430US, 431US, 436US, 437US, L2100-036US, L2300-038US, X Series (Slim): X320, X340, X350, X360, X400, X410, X420, X430, X480 |

| Tip | V | Samsung |
|---|---|---|
| H | 19V | N310 Series: N310-13G, N310-13GB, N310-13GM, N310-13GO<br>N Series: N110, N110-12PKB, N120, N120-12GBK, 12GW, 13GBL, N130, N130-13B, 13P, N135, N140, N140-14B, 14R, N150, N210, N220, N315, N510, N510-13P<br>NB Series: NB30, JA01US<br>NC Series: NC10, NC10-11GP, 12PWBK, 13GB, 13P, 14GB, 14GBK, 14GW, NC20, NC20-21GBK |
| P | 19V | **ATIV SMART PC PRO Series 7** XE700T1A, XE700T1A-A01US, XE700T1A-A03US, XE700T1A-A04US, XE700T1A-A05US, XE700T1A-A06US, XE700T1A-A01, XE700T1A-A02, XE700T1A-A04, XE700T1A-A05 |

| Tip | V | Toshiba |
|---|---|---|
| C | 19V | AC Series (UK): AC100, Mini NB Series: NB100, NB105, NB200 Series, NB200-00C, NB200-00D, NB200-00P, NB200-10F, NB200-10G, Nb200-10J, NB200-10Z, NB200-110, NB200-113, NB200-11H, NB200-11L, NB200-13T, NB202-107, NB205-N210, NB205-N211, NB205-N230, NB205-N310/BN, NB205-N310BNG, NB205-N311/W, NB205-N312/BL, NB205-N313/P, NB205-N323BN, NB205-N324BL, NB205-N324WH, NB205-N325BN, NB205-N325PK, NB205-N325WH, NB205-N330BL, NB205-N330BN, NB205-N330PK, NB205-N330WH, NB205-SP2920, NB205-Sp2921, NB205-SP2922, NB205-SP2923, NB205-SP2924, NB255-N240, NB255-N245, NB255-N250, NB305-N310, NB305-N310G, NB305-N410BL, NB305-N410BN, NB305-N410BN-G, NB305-N410WH, NB305-N411BL, NB305-N413BN, NB305-N415BL, NB305-SP1051, NB305-SP1052, NB305-SP2001, NB305-SP2002, NB350-N310, NB350-N410 |
| B | 15V | Portege Series: 2000 Series, 4000 Series, 4010 Series, M100 Series, M300 Series, R100 Series, Tecra Series: 9000 Series, 9100 Series, S, Satellite Series: 230 series, 300 series, 1555, 2060, 2100 seires, 2200 series, 2500 Series, 2600 Series, 2710, 2750, 2770, 4000 Series, Pro 300 Series, Pro 400 Series, Pro 440 Series, Pro 460 Series, Pro 470, Pro 480, Pro 490, Pro 4200 Series, Pro 4300 Series, Pro 4600 Series |

| Tip | V | Sony |
|---|---|---|
| A | 10.5V | VPC-W Series, W111XU, W111XX, P, PC, T, W, W112XX, P, T, W, W115XG, W115XGP, W115XW, P,T,W, W117XC, P,T,W, W119XJ, P,W, W11AXJ, W11S1E, P,T,W, W121AX, P, Q, T, W, WZ, W126AG, W127JC, P,T,W,WZ, W12AAJ, W12AKJ, W12AVJ, W12S1E, P,T,W, W211AX, L, P, T, W, W212AX, WI, W215AX, L, P, T, W, W216AG , W217JC, L,P,T,W, W218JC, L,P,T,W, W219AJ, L,P,W, W21AAJ, W21AKJ, W21AVJ, W221AX, VPC-M Series, Model, M11M1E, B, W, M12M1E, L,P,W, |
| F | 19.5V (19V) | VGN-P Series: P11Z, G, Q, R, W, P13GH, Q, W, P15G, G, Q, R, W, P17H, G, Q, R, W, P19VN/Q, P19WN/Q, P215/W, P31ZK, Q, R, P33GK, P35GK, P39VL/Q, P45GK, N, P, Q, W, P50, G, R, W, P530CH, G, Q, R, W, P530H, G,Q,R,W, P530N, Q, P588E, Q, R, P598E, Q, P610, G, N, Q, R,W, P61S, P688E, G,N,Q,R,W, P698E, Q, R, P699E, Q. R, P70H, G, R, W, P720K, Q, R, P72K/W, P788K, G, N, P, Q, R, W, P798K, Q, P799L, Q, P80H/W, P90HS, P90NS, P90S, P91HS, P91NS, P91S, P92KS, P92LS, P92VS, VPC-P Series: P111KX, B, D, G, P, W, P113KX, B, D, G, P, W, P114XK, B, D, G, P, W, P115JC, B, D, G, P, W, P115KG, P116KX, B, D, G, P, W, P116KG, P118JC, B, P, W, P118KX, B, D, G, P, W, P119JC, P100 Series, P115IE, B, D, G, W, VPG Series: CKP1B, CKP1T, CKP1W, VPC-X Series: X131, X131KX, B,N,P,S, X135 |